
About this document

This document provides the following:

- a list of compatible slots for circuit cards used in options 21A, 21, 21E, 51, 51C, 61, 61C, 71, 81, and 81C
- a general procedure for initially installing a circuit card
- acceptance tests for circuit cards that provide service functions, network control, and line and trunk connections
- option settings for the PBX circuit cards currently supported by Northern Telecom

Note: For information on equipment used with system option 11, see the appropriate documentation for that product.

- sample option settings for system configurations with NT8D22 System Monitors

For detailed procedures for removing a specific circuit card and installing a replacement, see *Meridian 1 hardware replacement* (553-3001-520).

For option settings on telephones, attendant consoles, or add-on modules, see the appropriate document for that equipment.

For a description of all administration programs and maintenance programs, see the *X11 input/output guide*. For information about system messages, see the *X11 system messages guide*.